



Omega bracket - spacer

EY-O/SWT

The Omega spacers can be used with the Omega intermediates, end and corner posts to space these posts away from the fence or wall. The spacer when used on a wall or any flat surface will give you a spacing of 28 mm between the wall and the Omega post. Two spacers can be used together to double the spacing.



The Omega spacer has a curved base which allows it to be also mounted onto a round tube. The spacing when used on a round tube will be 23mm. The five different mounting hole options on the spacer make it very flexible for different needs.

Features:

- Heavy duty design
- Large location plates allow for increased tolerance
- The five different mounting hole options.
- Quick fit design

Specifications:

UV stabilised plastic